

## Glass Width Calculation (6-8-10mm)

$$\begin{aligned}
 &\text{System Width (Frame profile) Dimension (4002)} - \text{Intermediate Space Between Side Column and Glass (27+27=54)} - \text{Space Between Two Glasses (6 mm)} - \text{Intermediate Glasses Quantity (5)} = \text{Measure to be Divided by Quantity of Glass panels (3918)} / \text{Panels Quantity (6)} = \text{Glass Width (653)}
 \end{aligned}$$

## Glass Height Calculation (6-8-10mm)

$$\text{System Height (2000)} - \text{Dimension to be Deducted for the Frame Profile, Glass Channel in Base Profile and Working Space (131)} = \text{Glass Height (1869)}$$

## Side Column Length Calculation

$$\text{System Height (2000)} - \text{Dimension to be Deducted for the Frame Profile and Side Column Equipment (86)} = \text{Side Column Height (1914)}$$

## Seal Length Calculation

$$\text{System Height (2000)} - \text{Dimension to be Deducted for the Frame, Base Profiles and Working Space (179)} = \text{Seal Height (1821)}$$

## INFORMATION - NOTE

### Angle Values to Be Taken For Frame Profile to Calculate Glass Width in Angled Balconies

→ Deducted measure for 90 degree angle	27 mm
→ Deducted measure for 135 degree angle	13 mm

### Base Profile Calculation

→ Deducted measure for Intermediate Cover	4.5 mm
→ Deducted measure for Side Column Cover	15 mm
→ Deducted measure for 90 degree angle	15 mm
→ Deducted measure for 135 degree angle	4.5 mm